


MBO

PAPER FOLDING MACHINES



**OPERATION AND
MAINTENANCE
MANUAL**

B 26/30

MBO



THE MBO - FOLDERS ARE DESIGNED WITH THE OPERATOR IN MIND, INCLUDING MAXIMUM EASE OF OPERATION, CONVENIENT PRECISION ADJUSTMENTS AND SAFETY. ALL MODELS ARE CONSTRUCTED SO AS TO BE AS HAZARD FREE AS POSSIBLE. ALL RULES PERTAINING TO THE SAFE OPERATIONS OF EQUIPMENT AND MACHINERY MUST BE ADHERED TO. IN ADDITION, THE WORKING AREA AROUND THE MACHINE MUST BE KEPT NEAT, FREE OF OBSTACLES AND LIQUID SPILLS.



TURN OFF INCOMING POWER TO THE MACHINE WHENEVER MAINTENANCE OF ANY KIND IS BEING PERFORMED, INCLUDING LUBRICATION AND CLEANING.

THE ATTENTION - LABEL ON THE ELECTRICAL CABINET INDICATES THAT THE MAIN SWITCH MUST BE TURNED OFF PRIOR TO OPENING.



VORSICHT! ATTENTION! ATENCION!

**VOR DEM OFFNEN SCHRANKINNERES
SPANNUNGSLOS MACHEN!**

**PRIOR TO OPENING BE SURE THAT INSIDE
OF CABINET IS DEAD!**

**AVANT D'OUVRIR, VERIFIEZ QUE L'INTERIEUR
DE L'ARMOIRE SOIT SANS TENSION!**

**ANTES DE ABRIR, ASEGURARSE QUE EL
INTERIOR DEL ARMARIO ESTE SIN TENSION!**



ATTENTION!
WHEN THE MAIN SWITCH
IS TURNED OFF, THE
CABINET IS NOT
COMPLETELY WITHOUT
VOLTAGE.

THE ATTENTION-LABEL ON THE ELECTRICAL CABINET STATES THAT THE CABINET IS NOT COMPLETELY WITHOUT VOLTAGE.



DO NOT OPERATE YOUR MBO -FOLDER WITH ANY OF THE GUARDS REMOVED OR WITH ANY OF THE SAFETY DEVICES DISCONNECTED, BYPASSED OR OUT OF ORDER.



DO NOT WEAR LOOSE CLOTHING AROUND THE MACHINES AND KEEP LONGER HAIR SECURELY TIED UP. REMEMBER THAT THESE MACHINES ARE DESIGNED TO GRIP AND HOLD MATERIAL AND MOVE IT AT HIGH SPEEDS.



DO NOT ATTEMPT TO MAKE ANY ADJUSTMENT ON THE MACHINE WHILE IT IS IN MOTION, UNLESS ADJUSTING DEVICE OR CONTROLS ARE PROVIDED AND THE ADJUSTMENT IS SPECIFICALLY MENTIONED AS A RUNNING ADJUSTMENT.



IF MECHANICAL FAILURE SHOULD OCCUR, OR IF ADJUSTMENTS APPEAR TO BE NECESSARY THAT ARE NOT PART OF THE NORMAL OPERATOR'S PROCEDURES, SHUT THE MACHINE OFF. GET ASSISTANCE FROM YOUR MBO SERVICE REPRESENTATIVE.



DO NOT, UNDER ANY CIRCUMSTANCES, ATTEMPT TO WORK ON OR OVER THE MACHINE WITH TOOLS OF ANY KIND WHILE IT IS RUNNING.



SHOULD A PROBLEM DEVELOP THAT APPEARS TO BE ELECTRICAL IN NATURE, SHUT THE MACHINE OFF. TURN OFF INCOMING POWER TO YOUR MACHINE. SECURE THE SERVICES OF AN ELECTRICIAN OR YOUR LOCAL MBO SERVICE REPRESENTATIVE.



DO NOT ATTEMPT TO REMOVE A PAPER JAM, NO MATTER HOW MINOR IT MAY APPEAR TO BE, WHILE THE MACHINE IS IN OPERATION.



WHEN CLEANING THE FOLD ROLLERS, USE THE HANDWHEEL FOR TURNING. BE SURE THE POWER OF THE MACHINE IS OFF.



TURN OFF THE POWER TO THE MACHINE BEFORE MAKING ANY ADJUSTMENTS TO SCORING, PERFORATING, OR SLITTING ATTACHMENTS. KEEP HANDS AND CLOTHING AWAY FROM SLITTER SHAFTS WHILE THE MACHINE IS RUNNING.



USE EXTREME CAUTION WHEN HANDLING SLITTER SHAFTS ACCESSORIES. THE BLADES ARE VERY SHARP AND CAN CAUSE SERIOUS CUTS.



WHEN THE (WHITE) PILOT LIGHT ON MAIN CONTROL PANEL IS ON, USE CAUTION. THE MACHINE CAN BE SET IN MOTION FROM ANOTHER CONTROL STATION.



NO PARTS OR MATERIALS SHOULD AT ANY TIME BE PLACED ON ANY SECTION OF YOUR MBO FOLDER, EVEN WHEN POWER IS OFF.



THERE IS A STOP BUTTON ON ALL ELECTRICAL CONTROL PANELS AT THE 8, 16 AND 32 PAGE UNITS OR ON THE MOTORIZED STACKER'S.



WHEN THIS BUTTON IS PUSHED, ALL CONTROL-POWER IS CUT OFF TO ALL MACHINE SECTIONS.

GENERAL DESCRIPTION T46/B18, T49/55, B23, B123, T65, T75, B26, B30

The above folding machines were developed for folding sheets in the sizes as specified in their respective data sheets using pile or continuous feeders (see page 1A). The running speed can be regulated continuously from 200 to 8000 inch/min. depending on the machine and can be varied according to size of the sheet or kind of folding.

The basic machine is supplied with a pile or continuous feeder and the well-proven MBO features of:

- * Lattice-type alignment table
- * Four (4) fast setting fold plates with attached swinging deflectors and a new sheet stop adjustment
- * Combination polyurethane-steel spiral rollers with new gearless and noiseless belt drive and caliper adjustment at the top of the machine
- * Solid, quick change, easily removeable knife shafts equipped with plug bearings

The 8-page station is a roll-a-way buckle folding unit with its own drive, quiet running cross carrier rollers, and four (4) plates etc. as described above.

The 16-page station is also a roll-a-way buckle folding unit as described above, but with 12" or 15" working width and four (4) fold plates.

The 32-page station has two (2) plates in a 15" working width.


The knife unit "X" can be used on the parallel or the 8-page buckle unit of the B18/T46/T49 as an 8-page or 16-page folding unit. The knife is self-timing by a photocell and is independent of the feeder.

The standard delivery is a hang-on motorized stacker delivery with electronic speed control for the T46/B18/T49/T55 and early B23 folders. The newest B23 and B123, B26/B30 folders use a mobile motorized stacker delivery as standard.

To give the operator a general understanding of the working of the machine, the following description is made in the sequence of the adjustment of the machine from feeder to delivery.

	Sheet Size Min.	Sheet Size Max.	Running Speed Inches/Min.
T46/B18 Pile	4" x 6"	18" x 26"	1575 to 7000
T49 Pile	4" x 6"	20" x 27"	1600 to 7600
T49 Cont.	4" x 6"	20" x 36"	1600 to 7600
T55 Pile	4" x 6"	22" x 31"	1600 to 5600
T55 Cont.	4" x 6"	22" x 36"	1600 to 5600
B23 Pile	4 1/4" x 6"	23" x 36"	1600 to 8000
B23 Cont.	6" x 7"	23" x 50"	1600 to 8000
B123 Pile	4 1/4" x 6"	23" x 36"	1450 to 8000
B123 cont.	6" x 7"	23" x 50"	1450 to 8000
T65 Cont.	6" x 7"	26" x 50"	1600 to 6700
T75 cont.	6" x 7"	30" x 50"	1600 to 6700
B26 cont.	6" x 7"	26" x 50"	200 to 7200
B30 Cont.	6" x 7"	30" x 50"	200 to 7200

Diagram of production speed for combi- and buckle folding machines




Example:

If sheet length is approx. 24 inches,
 demanded speed to sheet is 4800 inches/min.
 broken line shows production of 10000 sheets/hour.

MBO


B26/B30 CONTINUOUS FEEDER WITH IZVA342 T COUNTER



ITEM	DESCRIPTION	NO.	PART NO.	ID. NO.
1	MAIN SWITCH	Q1	KCF2Y/K4C003H	0126995/0126953
2	AIR PUMP SWITCH	Q2	KBC1B/K3C003H	0127068/0126961
3	PILOT LIGHT FOR (1) BULB	H1	D1V1W/DFSN 2WBA9S-42V	0127183/0127225 0126136
4	EMERGENCY STOP	S1	D1C1R/DA11	0127076/0127027
5	PILOT LIGHT FOR (4) BULB	H3	D1V1G/DA11 2WBA9S-42V	0127209/0127225 0126136
6	MACHINE "OFF"(STOP)	S2	D1A1R/DA11	0127126/0127027
7	MACHINE "ON"(START)	S3	D1A1G/DA11	0127118/0127027
8	PILOT LIGHT RESET BULB	H4	D1V1Y/DFSN 2WBA9S-42V	0127217/0127225 0126136
9	SPEED CONTROL POTENTIOMETER	R1	D3R1S/AWI0K0HM	0127274/0126375
10	PILOT LIGHT FOR (11) BULB	H2	DFSN11 2WBA9S-42V	0127266 0126136
11	SHEET FEED BUTTON INCLUDING BULB	S4	D1Y1B/DFSN11 2WBA9S-42V	0127258/0127266 0126136
12	SHEET GAP SETTING		71072	0131914
13	VACUUM LENGTH SETTING		71071	0131916
14	SELECTOR SWITCH FOR BATCH IMPULSE	S8	D1G2R/DA11	0127142/0127027
15	BATCH COUNTER/ SPEED IND. (OPTIONAL)		IZVA342 T	
16	FEEDER BELT SPEED (SLOW SPEED ONLY)	R2	D3R1S/AW10K0HM	0127274/0126375

MBO


B26/B30 CONTINUOUS FEEDER WITH MCC2 COUNTER



ITEM	DESCRIPTION	NO.	PART NO.	ID. NO.
1	MAIN SWITCH	Q1	KCF2Y/K4C003H	0126995/0126953
2	AIR PUMP SWITCH	Q2	KBC1B/K3C003H	0127068/0126961
3	PILOT LIGHT FOR (1) BULB	H1	D1V1W/DFSN 2WBA9S-42V	0127183/0127225 0126136
4	EMERGENCY STOP	S1	D1C1R/DA11	0127076/0127027
5	PILOT LIGHT FOR (4) BULB	H3	D1V1G/DA11 2WBA9S-42V	0127209/0127225 0126136
6	MACHINE "OFF"(STOP)	S2	D1A1R/DA11	0127126/0127027
7	MACHINE "ON"(START)	S3	D1A1G/DA11	0127118/0127027
8	PILOT LIGHT RESET BULB	H4	D1V1Y/DFSN 2WBA9S-42V	0127217/0127225 0126136
9	SPEED CONTROL POTENTIOMETER	R1	D3R1S/AW10KOHM	0127274/0126375
10	SHEET FEED BUTTON INCLUDING BULB	S4	D1Y1B/DFSN11 2WBA9S-42V	0127258/0127266 0126136
11	SHEET GAP SETTING		71072	0131914
12	VACUUM LENGTH SETTING		71071	0131916
13	BATCH COUNTER/ SPEED INDICATOR		MCC2	
14	FEEDER BELT SPEED (SLOW SPEED ONLY)	R2	D3R1S/AW10KOHM	0127274/0126375

MBO OPERATION AND MAINTENANCE MANUAL

SETTING SHEET GAP AND VACUUM LENGTH



INSTRUCTION FOR SETTING THE TWO DIGITAL DISPLAYS ON THE MAIN CONTROL PANEL OF : B18, T46, T49, T55, B23, B123, T65, T75, B26 & B30.

- 1 THE LEFT-HAND DISPLAY WITH 3 DIGITS IS FOR SETTING THE SHEET GAP. THE DISTANCE ACTUALLY SET ON THE DISPLAY IS THE DISTANCE FROM THE FRONT EDGE OF ONE SHEET TO THE FRONT EDGE OF THE NEXT FOLLOWING SHEET, I.E. SHEET LENGTH AND GAP.

THIS DISTANCE IS SET IN CENTIMETERS INTO THE DISPLAY AND ITS APPROXIMATE EQUIVALENT CAN BE CONVERTED FROM THE INCH SYSTEM INTO THE METRIC SYSTEM BY MULTIPLYING THE INCHES BY 5 AND DIVIDING THE RESULTING FIGURE BY 2:






EXAMPLE: IF WE TAKE A SHEET 28" LONG AND WE REQUIRE A GAP OF 4" THEN TOTAL SHEET LENGTH PLUS GAP EQUALS 32".
 $32" \times 5 = 160$
 $160 \div 2 = 80$ CENTIMETERS TO BE STORED INTO 1 AS 080.

- 2 THE RIGHT-HAND DISPLAY WITH 2 DIGITS IS FOR SETTING THE VACUUM LENGTH. THIS IS THE DISTANCE THE SUCTION WHEEL IS IN VACUUM CONTACT WITH THE SHEET, AGAIN, IN CENTIMETERS. THIS IS NORMALLY SET AT APPROXIMATELY 1/3 THE LENGTH OF THE SHEET. WITH THE ABOVE EXAMPLE THIS WOULD BE 23 CENTIMETERS.


EXAMPLE: $28" \times 5 = 140$
 $140 \div 2 = 70$ CENTIMETERS
 $70 \times 1/3 = 23$ CENTIMETERS

SETTING OF SHEET GAP

INCHES SHEET LENGTH	0 0 SET	0 0 SET
6	020	10
8	025	12
10	030	15
12	035	18
14	040	20
16	045	24
18	050	25
20	055	27
22	060	30
24	065	30
26	070	30
28	075	30
30	080	30
32	087	33
34	092	33
36	098	33
38	104	33
40	110	35
42	115	35
44	120	35
46	125	35
48	130	35
50	135	35



- 1 Loading of feeder
 - 1.1 Setting of side lay (L)
 - 1.1.1 loosen set screw (F)
 - 1.1.2 set sidelay (L) according to scale (S) for half width of sheet.
Sidelay can be used on either left or right side
 - 1.1 Guide tapes (B) adjustment
 - 1.2.1 Set one tape on each side of sheets approximately 1/2 inch inside edge of sheet (A) use guide (C)
 - 1.3 How to load sheets
 - 1.3.1 Put a load of 1 to 1 1/2 inch of sheets on top table, and fan out. Important: all sheets should be "aired" before loading
 - 1.3.2 Put next load in same manner on table
 - 1.3.3 If tail of stock reaches left end of table (H) push the blue sheet feed bottom to start movement of tapes around drum towards suction wheel
 - 1.3.4 Sheets can be loaded up to top of sidelay (L)
 - 1.4 Adjustment of rear tapes
 - 1.4.1 The tapes (B) around rear drum are adjustable in pressure
 - 1.4.2 Bracket (E) to the right-more pressure (E) to the left-less pressure
 - 1.4.3 Sheets should be held on to drum with little pressure, or not hanging away more than 1/2 inch at position (D)



2. Sheet-transport-control

Sheet transfer from top board around the drum to suction wheel is made with a two speed system

2.1 A feeler tongue (Z) is moving to the right. If no sheets are under suction drum, in this position sensor (A) switches on transport mechanism to "fast speed"

2.1.1 Fast speed approximately 6 feet/min.

2.2 Working Position:

If sheets reach tongue (Z) they push it to the left

2.2.1 The bottom of tongue is leaving sensor (A) and switches transport tapes to "slow speed"






2.2.2 Slow speed approximately 2 feet/min.

2.3 Final Position:

The sheets are pushing tongue (Z) more to the left

2.3.1 The bottom of tongue is reaching sensor (B) and stops the transport tapes

2.4 The distance (C) from bottom of tongue to sensor (A) or (B) must be between 0,5 and 1 mm



2.5 Adjustment of feeler tongue

Feeler tongue (Z) is adjustable in two dimensions. This is important if front edge of sheets are curled either up or down

2.5.1 With knob (A) you move tongue (Z) forward or back

2.5.2 With knob (B) you move tongue (Z) up or down

2.5.3 If using down-curved sheets adjust tongue (Z) down with knob (B)

2.5.4 At same time adjust tongue (Z) back with knob (A) (to right)


2.5.5 If using up-curved sheets adjust tongue (Z) up with knob (B) otherwise sheets are moving between tongue (Z) and suction wheel (S) too far forwards (overrun) results are double sheets

2.5.6 At same time adjust tongue (Z) to the left (forwards)

2.6 If handling curled sheets, the pick up position (P) on suction drum (S) can be changed


2.6.1 On up-curved sheets, move pick up position (P) forwards (clockwise)

2.6.2 On down-curved sheets, move pick up position (P) backwards (counter clockwise)




2.7 Sheet hold down

On up-curved sheets it is possible that they overrun tongue (Z) and transport stops too late, this creates a lot of double sheets. With the adjustable holddown (N) we can prevent this




2.7.1 Position holddown (N) on left side of suction drum (S) on bar (T)




2.7.2 With knurled screw (E) adjust smoother tongue down until sheets are no longer overriding tongue (Z)

2.8 Guide plate below sheets


To get best running conditions, the bottom plate (L) between transport belt (B) and suction drum (S) is adjustable up or down




2.8.1 On down-curved sheets adjust plate (L) up to a higher position



2.8.2 On up-curved sheets adjust plate (L) down to a lower position






2.9 Tail drag


To control the tail end of sheets we use two soft wheels (M) and one brush (B) adjustable at (A)

2.9.1 Adjust wheels (M) on arm (A) to end of sheets, so that 3-5 sheets are held

Between the two wheels (M) there is a brush (B) with an adjustable weight (G) (weight standard only on R105 and T102/112 feeders part no. 1.0.3744.010)




2.9.2 If feeder is pulling double sheets, move weight (G) forwards (to left) for more pressure. If unsteady feeding appears, move weight backwards (to right)



2.10 Loading capacity:

To increase the loading capacity on top board, there are extension elements (V) available. They can be mounted on cross bar (T) near suction drum

(important on large sized sheets)



The air pressure and vacuum pump is turned ON by use of switch no. 2 at the main control panel. Open the required airclips, which are placed on the air tube at the front of the pile. The quantity of air should be proportioned in such a manner that approximately 5 to 10 sheets of the pile are thoroughly ventilated. The air tube may be adjusted up or down by twisting the knurled-head screw, which is located on the left side of the air tube. The air tube may also be tilted by use of the lever, which is also located on the left side of the air tube. You may carry out the preceding adjustment if the front edge of the sheet pile is bent down to achieve better results.

T46/B18/T55/T65






The conveyance of vacuum from the suction wheel is controlled by a disk which is placed behind the suction wheel. A red mark is located on this disk. The same marking is located on the housing beside the disk. When these marks are lined up the sheets are sucked by the suction wheel vacuum in their exact center. A lever is located on the front left-hand side of the disk for adjustment of the exact vacuum contact position. If the sheet bends down you should move the lever to the right (clockwise). The starting position for normal (even) pile is, when the 2 red marks behind the suction wheel are lined up.

B23/B123/B26/B30

The conveyance of vacuum from the suction wheel is controlled by a disk which is placed behind the suction wheel as above; however, the adjustment lever and ball knob are at the top of the disk behind the suction wheel.

Double sheet control:

The double sheet control is located in front of the alignment table. A lever is located at the side of the double sheet control which is to be used to insert a piece of paper below the feeler screw. This piece of paper is to be taken from the pile which is being processed. In order to exactly adjust the double sheet control you should turn ON the machine. Place one paper strip (from the pile which is to be processed) underneath the caliper, thereby preventing interruption of the sheet infeed mechanism. If two paper strips are placed between the caliper and the lower roller then the sheet infeed should stop (machine still keeps running). If a readjustment becomes necessary, this may be carried out by use of the knurled-head screw, in order to lift or drop the caliper, and to grant the necessary sensitivity.



3. Airblast and sheet separation

Lifting and separation of sheets is performed from two sides. Between suction drum and alignment table is an airtube (B) across front of sheets. On left side of feeder is a self adjusting air nozzle (P)


3.1 On airtube (B) are many holes across entire width of feeder. These holes can be opened or closed with clips (C) picture (D) open, (E) closed

3.1.1 Open all holes for the size of sheet


3.1.2 Holes outside of sheet size keep closed with clips (C)

3.1.3 Airtube (B) can be turned with lever (F) and secured with screw (G)


3.1.4 Air tube (B) is adjustable up or down with knurled screw (H)



3.1.5 Most efficiency in sheet separation is obtained when air reaches sheets at a flat angle




3.1.6 On down-curved sheets move airtube (B) down with screw (H) and turn airblast direction up with lever (F)



3.1.7 On up-curved sheets move airtube (B) up with screw (H) and turn airblast direction down with lever (F)

3.1.8 If airtube is turned up too far, a lot of air escapes over sheets to atmosphere (bad separation, doublesheets)



3.1.9 The best result is obtained only by using the rippled air guide plates (L). The air goes along the plate to sheets and provides the best separation. Keep plate (L) over air-hole

Alignment table (register table)

When a sheet leaves the feeder, it is carried by the alignment tape towards the parallel unit along the side guide. You may adjust the side guide by setting the side guide to one-half of the sheet width using the scale on the cross bar. This set-up should correspond with the setting of the pile stop at the pile table. You may use the fine adjustment located at the mounting block of the side guide for small adjustments. You equip the ball rail with either plastic or steel balls to keep the sheets close to the side guide. The first five holes of the ball rail after the suction wheel should always contain steel balls in order to exert sufficient pressure onto the sheet and to increase the speed of infeed.

Now insert plastic balls after the first five steel balls when you process light paper. Medium and heavy weight paper sheets require steel balls as much as necessary.

To achieve exact folding in the 8-page unit, it is absolutely necessary that the sheets are fed at a right angle from the alignment table into the buckle plates of the parallel unit. There is a fine adjustment on the side guide (close to the double sheet control) to set the guide at a right angle to the fold rollers. It requires that you loosen the plastic knob, which enables you to set the correct position by turning the eccentric bushing.

Parallel Unit:

The sheet is leaving the alignment table towards the parallel unit where it, due to the buckle plates and deflectors, obtains one or multiple folds. All buckle plates have scales to set the sheet for the fold required fold, and swinging deflectors which may be brought easily into position as required.

Buckle plates:

Fold plate depth (inches)

T46/B18

<u>Parallel</u>				<u>8-Page</u>				<u>16-Page</u>			
#1	#2	#3	#4	#1	#2	#3	#4	#1	#2	#3	#4
21	21	14	14	14	14	14	14	-----	-----	-----	-----

T49/55

<u>Parallel</u>				<u>8-Page</u>				<u>16-Page</u>			
#1	#2	#3	#4	#1	#2	#3	#4	#1	#2	#3	#4
21	21	14	14	14	14	14	14	14	14	14	14

B23/B123

<u>Parallel</u>				<u>8-Page</u>				<u>16-Page</u>			
#1	#2	#3	#4	#1	#2	#3	#4	#1	#2	#3	#4
21	21	14	14	21	14	14	14	14	14	14	14







B26/30

<u>Parallel</u>				<u>8-Page</u>				<u>16-Page</u>			
#1	#2	#3	#4	#1	#2	#3	#4	#1	#2	#3	#4
25	20	14	14	20	20	14	14	14	14	14	14

T65/75

<u>Parallel</u>				<u>8-Page</u>				<u>16-Page</u>			
#1	#2	#3	#4	#1	#2	#3	#4	#1	#2	#3	#4
25	20	14	14	20	20	14	14	14	14	14	14

The minimum size of product of each buckle plate is approximately 1.5 inches.



3.2 Too much airblast:

The new turbo type air pump supplies a sufficient airblast. If handling small size sheets, the top sheets are blowing back beneath the suction drum

To avoid this, air can be released on a valve (V) on each side of feeder

3.2.1 Valve (V) closed maximum airblast

3.2.2 Valve (V) open minimum airblast





3.3 Side blower:

On left hand side of feeder is a self adjusting air nozzle (P) depending on sheet size, this air nozzle can be moved backwards or forwards. This blower should lift the rear half of sheets

3.3.1 Place blower in rear half of sheets

3.3.2 Adjust counter weight (G) to keep balance of blower. Blower should touch slightly the top of sheets.

3.3.3 Adjust airblast with valve (X) in a manner that all top sheets are separated exactly



3.2. The airblast from air tube (C) is to be regulated through the regulating chokes 1 and 2. In order to achieve a proper sheet separation a well ventilated package of approximately 15 sheets is required.

3.2.1. Regulating choke 3 is to regulate the airblast for side blower.

3.2.2. Position (A) maximum airblast
Position (B) closed - no airblast

If handling small size sheets, the top sheets are blowing back beneath the suction drum:

- to avoid this you can close more of the regulating chokes 1 and 2 and completely close choke 3 for side blower.

3.3. Side blower

The self adjustment air nozzle (P) which is on the left hand side of feeder, depends on sheet size, this air nozzle can be moved backwards or forwards.

This blower should lift the rear half of sheets.

3.3.1. Adjust counter weight (G) to keep balance of blower.

Blower should slightly touch the top of sheets.

How you ascertain which buckle plate to use:

Fold a sheet by hand of the job to be processed. Prepare the necessary folds which are required for this job. Check the imposition and determine the head and side lay of the sheet. Select the buckle plate (s) which are necessary for the required fold(s) and adjust the buckle plate (s) in accordance with the hand-folded sheet.

Setting of buckle plates or deflectors:

After determining which buckle plate is required for a certain job, you set the deflectors into position. You lower the deflectors on the buckle plates which are not required, and you lift the deflectors of the buckle plates which are required. This occurs as follows:

Loosen the plate lock-up levers to release the buckle plates. Pull the buckle plate away from the fold rollers and "swing" the deflector into the required position. Reposition the buckle plate and tighten the plate lock-up lever.

Setting the sheet stop:

The sheet stops are adjusted with a handwheel for the correct fold length within the range of the buckle plate. Set according to the scale belt and plate indicator.

Fold plate and Fold Roll settings:

This section has been prepared to assist the machine operator. We have not made an attempt to show all kinds of folding impositions which can be made on the folder. If it is necessary you may, in addition to those we are showing you, fold other types of impositions.


The buckle plates which are used at the parallel, 8-page, and 16-page units 2nd, 3rd, and 4th. The calipers for setting the fold rolls and knife shafts are located on top of each side frame, and are numbered continuously.

Caliper no.1 moves the fold roller no.2, and caliper no. 2 moves the fold roller no.3, and so forth.

Correct Roller pressures and how to accomplish them

The most common fault is that the operator tends to use too much roller pressure. The method used to obtain the correct roller pressure is:

- a. Draw back all buckle plates from the fold rollers.
- b. Insert one piece of paper below each caliper on both sides of the machine.
- c. Then, using the same paper, tear strips approximately 2" wide x 8" long and insert them between the rollers approximately 3" from the ends of the roller that you are correcting--one roller at a time.
- d. Then hold one piece of paper with one hand, and with the other, turn the hand wheel in the direction that the machine normally travels and feel the roller "drag" on the paper. The rollers should have enough pressure to kiss the paper and transport the sheet when the machine is in motion. If the paper tears, then you should turn the caliper knob clockwise. If you have too little pressure, turn the knob counterclockwise. This should be done on both extreme ends of each roller in turn. If the pressures are "far out", do one end and then the other but come back to the first side again and recheck. You may have to do this several times.
- e. After this procedure has been carried out at all fold rollers including the knife shaft, you may set the scale of the calipers to 0 position by holding the caliper and turning the graduated collar to the 0 marking (Fig. 1).
- f. If at any time, you wish to make (small/micrometer) adjustments to the roller pressure, you can then check the scale and re-zero the rollers by just turning the



4. Sheet guide:




In final position, there are two guides to hold sheet in position

4.1 On right hand side is a side guide (L)


4.2 On left hand side is a guide pin (F)

4.1.1 Put side guide (L) up to sheets on right hand side and tighten with set screw (K)

4.2.1 Set guide pin (F) approximately 2-3 mm (1/8") away from left hand side of sheets. Tighten with set screw (R)



4.2.2 If handling short sheets move guide pin (F) to left side of bar

HOW TO ASSEMBLE THE NEW B123 / B26 / B30 CONTINUOUS FEEDER

FOR SPACE SAVING REASONS THE FEEDERS ARE SHIPPED WITH SIDE PLATE (a) AND ADJUSTING SCREW (b) DISASSEMBLED.

WHEN INSTALLING THE FEEDER, BE SURE TO ASSEMBLE THE PARTS ACCORDING TO THE SKETCH PROVIDED.





Illustration no. 1

Four pages parallel "buckle plate on top"

- Caliper no. 1.....Insert one (1) thickness of paper
- Calipers no. 2-6.....Insert two (2) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of the sheet length
- Deflectors no. 2-4... Set into position

1



Four pages parallel "buckle plate at bottom"

- Caliper no. 1 & 2.....Insert one (1) thickness of paper
- Caliper no. 3-6.....Insert two (2) thicknesses of paper
- Sheet stop no. 2.....Adjust to 1/2 of the sheet length
- Deflector no. 1.....Set into position

(Two up or multiple up may be folded and cut on the folding machine).

Illustration no. 2

Double parallel fold, 8 pages

2

- Caliper no. 1.....Insert one (1) thickness of paper
- Caliper no. 2.....Insert two (2) thicknesses of paper
- Caliper no. 3-6.....Insert four (4) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet length
- Sheet stop no. 2.....Adjust to 1/4 of sheet length
- Deflectors no. 3 & 4..Set into position




Illustration no. 3a

Parallel fold, 6 pages

- Caliper no. 1 & 2.....Insert one (1) thickness of paper
- Caliper no. 3-6.....Insert three (3) thicknesses of paper
- Sheet stop no. 1.....Adjust to 2/3 of sheet length
- Sheet stop no. 2.....Adjust to 1/3 of sheet length
- Deflectors no. 3 & 4 ..Set into position

3

Note: This imposition requires that the operator is keeping a large sheet gap (see setting of sheet gap).




Illustration no. 3 b

Parallel fold, 6 pages


- Caliper no 1-3.....Insert one (1) thickness of paper
- Caliper no 4-6.....Insert three (3) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/3 of sheet length
- Sheet stop no. 3.....Adjust to 1/3 of sheet length
- Deflectors no 2 & 4....Set into position


Illustration no. 4

Accordion fold, 6 pages

- Caliper no. 1 & 2.....Insert one (1) thickness of paper
- Caliper no. 3-6.....Insert three (3) thicknesses of paper
- Sheet stop no. 1 & 2...Adjust to 1/3 of sheet length
- Deflectors no. 3 & 4...Set into position

4






IMPORTANT: SHORT SHEET GUIDE STRAPS C MUST BE PLACED IN POS. D BEFORE LOADING PAPER ONTO FEEDER (TO CLOSE THE GAP BETWEEN THE SHAFT E + F)


VERY IMPORTANT: BEFORE YOU START LOADING THE FEEDER PLACE THE LINK BELT A SUPPORTS IN A UNIFORM DISTANCE FOR SHEET SIZE.


NOTE: SPRING OF LINK BELT SUPPORTS A SHOULD BE CONNECTED TO BOTTOM CROSS BAR B.

**IMPORTANT:**


THE SHORT SHEET GUIDE STRAPS C MUST BE PLACED IN POS. G BEFORE LOADING PAPER ONTO THE FEEDER.


THE TWO OUTER STRAPS SHOULD ALWAYS BE PLACED AT LEAST 1/2" FROM THE EDGE OF THE SHEET.





1. ON EXTREMELY CURLED SHEETS THE LONG PLASTIC STRAPS H ARE NEEDED IN POSITION APPROXIMATELY $\frac{1}{2}$ " FROM THE EDGE OF SHEET.
2. ALWAYS PLACE THE REQUIRED PLASTIC STRAPS H IN A UNIFORM DISTANCE ACROSS THE SHEET.
3. IF NORMAL PAPER IS PROCESSED, THESE LONG PLASTIC STRAPS ARE NOT REQUIRED. $\frac{1}{2}$ "





THE TWO GUIDING WHEELS J SHOULD BE USED ONLY IF
EXTREMELY SHORT SHEETS ARE PROCESSED.

Illustration no. 5

Accordion fold, 8 pages

- Caliper no. 1-3.....Insert one (1) thickness of paper
- Caliper no. 4-6.....Insert four (4) thicknesses of paper
- Sheet stop no. 1-3.....Adjust to 1/4 of sheet length
- Deflector no. 4.....Set into position




Illustration no. 6

Accordion fold, 10 pages

- Caliper no. 1-4.....Insert one (1) thickness of paper
- Caliper no. 5 & 6.....Insert five (5) thicknesses of paper
- Sheet stop no. 1-4.....Adjust to 1/5 of sheet length




Illustration no. 7

Parallel fold, 12 pages

- Caliper no. 1.....Insert one (1) thickness of paper
- Caliper no. 2-4.....Insert two (2) thicknesses of paper
- Caliper no. 5 & 6.....Inset six (6) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet length
- Sheet stops no. 2 & 4..Adjust to 1/6 of sheet length
- Deflector no. 3.....Set into position




Illustration no. 8

Parallel section adjust in accordance with illustration no. 1
Adjust 8-page section as follows:

- Caliper no. 1.....Insert two (2) thicknesses of paper
- Caliper no. 2-6.....Insert four (4) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet width
- Deflectors no. 2-4.....Set into position




Illustration no. 8

If at 8-page section "buckle plate at bottom" fold is required, adjust as follows:

- Caliper no. 1 & 2.....Insert two (2) thicknesses of paper
- Caliper no. 3-6.....Insert four (4) thicknesses of paper
- Deflector no. 1.....Set into position
- Sheet stop no. 2.....Adjust to 1/2 of sheet width
- Deflectors no. 3 & 4....Set into position

Illustration no. 9, 15 pages

Set parallel section as described in illustration no. 2, and adjust 8-page section as follows:

- Caliper no. 1.....Insert four (4) thicknesses of paper
- Caliper no. 2-6.....Insert eight (8) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet width
- Deflectors no. 2 - 4...Set into position




Illustration no. 10, 12 pages right angle

Set parallel section as described in illustration no. 3a and adjust 8-page section as follows:

- Caliper no. 1.....Insert four (4) thicknesses of paper
- Calipers no. 2 - 6.....Insert eight (8) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet width
- Deflectors no. 2 -4....Set into position





Illustration no. 11, 12 pages accordion and right angle

Set parallel section as described in illustration no. 4 and adjust 3-page section as follows:

- Caliper no. 1.....Insert three (3) thicknesses of paper
- Calipers no. 2-6.....Insert six (6) thicknesses of paper
- Sheet stop no. 1.....Adjust to 1/2 of sheet width
- Deflectors no. 2-4.....Set into position



How to assemble and disassemble knife shafts:

The scoring (creasing), perforating, cutting, and trimming devices as well as the transport rollers are installed onto the knife shafts. These shafts with their plug bearing feature may easily be removed from and reinstalled in the folding unit when a new job makes it necessary.

To remove the knife shafts, loosen the socket head screw, in the slot of the bronze bushing, which locks the socket plug. While holding the knife shaft firmly with one hand, pull the knob with the other hand. To take the knife shaft out of the folding unit, move it approximately 1/2 inch in the same direction.

The reassembly occurs in the same manner in reverse. In order to prevent any end play, make sure that the screw fits deep in the slot by pushing on the knob of the plug.

How to assemble and adjust scoring (creasing) knives:

Attach the scoring knife on a knife holder and hold it firmly by use of the locking nut. A hooked spanner is designed for loosening and tightening this nut.

If the scoring knife and a upper buckle plate is used for a job fold, this holder must be mounted with the nut facing the drive side of the machine on the upper knife shaft. If a fold job should be made in a lower buckle plate, the scoring knife must be installed onto the lower shaft with the nut facing the operator side of the machine.

Place the transport rollers (with radius) on both ends of the counter shaft. These rollers must be set into position on both sides of the scoring knife. By increasing or decreasing the distance between the rollers and the knife you may vary the depth of scoring.

How to install perforating knives:

Using the same type of knife holders and locking nuts, which are used for the scoring knives, you can assemble perforating knives on the knife shafts.

The knife must be assembled on the holder with its bevelled side in the direction of the locking nut. By keeping the locking nut in the direction of the drive side, the perforating knife can be installed on the upper shaft.

The counter knife is made of hardened steel and has two sharp edges. One of these edges should be placed against the flat side of the perforating knife. Do not press them firmly together, they should touch only lightly.

When both the perforating and the counter knife are adjusted place the smoother onto the square bar which is located beyond the knife shaft.

Use a 15-tooth perforating knife for heavy and medium paper sheets, and for light paper sheets use a 12-tooth perforating knife.

See enclosure TM 32 or TM35 for additional knives.

How to install cutting knives:

The cutting knife or slitter may be installed onto the upper knife shaft by use of the same holder which is used for the scoring and perforating knives. The cutting knife should be installed in such a manner that the locking nut is directed to the drive side. Once again, the lower (counter) knife is of hardened steel with sharp edges on both sides. One of the sharp edges should be placed against the flat side of the cutting knife. Do not press them firmly together, they should only touch lightly.

How to install the center bleed trim device:

To produce a center bleed trim a special knife holder is used. Assemble the knife (with its flat side against the holder) as well as the required washers, and a second knife (with its flat side) in the direction of the locking nut. The width of the holder is sufficient to produce a center bleed trim of approximately 3/4".

The lower shaft requires two hardened counter knives. Each counter knife must be placed into such a position that it lightly touches the flat side of the cutting knife. Place the steel stripper between the lower counter knives so that the paper waste is deflected down and away from the knife shaft.

How to place scoring and cutting knives as well as transport rolls into position:

Place the transport rolls at an equal distance to each side of the holder on the upper shaft and place the steel collars equally on the lower shaft. The transport rolls are serving the purpose of guiding the sheets after they have left the fold rollers. They also support the cutting, perforating, or scoring of the sheets, and lead them to the next unit (station) or to the delivery.

How you set the cross carrier's side lay of the 2nd folding unit:

This side lay may be set to each sheet size. A sheet, which had been folded at the parallel unit (1st folding unit), should be placed onto the cross carrier of the 2nd folding unit. Move the side lay out or inwards until the edge of the sheet rests approximately 1 inch inside the side edge of the cross carrier. Install the guide fingers equally on the side lay for the width of the sheet coming from the first folding unit, so that the sheet is kept directly under the ball rail.

Install the aluminum smoother bars spaced for the width of sheet, to guide it into the fold rollers of the second folding unit.

The plastic and steel balls, which are delivered with the cross carrier, have the same effect as those balls on the aligning table after the feeder. The quantity of the balls to be used and their distribution in the ball rail depends on the weight, size, and kind of paper which has to be processed.

In order to achieve an exact fold at unit 2, the side guide of the cross carrier may be set by use of the angle adjustment. The small stargrip serves as a locking device, and the knurled ring serves as an eccentric.

The sheets which are leaving the parallel unit onto the cross carrier may be supported by making a height adjustment. The rear leg of the cross carrier is equipped with a caster and brake for the exact positioning of the 2nd folding unit. Loosen the setting screw to set the cross carrier height, then lift or drop the complete cross carrier table and re-tighten the setting screw.

Delivery:

The delivery, hang on or mobile, which is delivered with the folding machine, may easily be used at all exits. When the job is finished, the folded sheets are led to the transport belt(s) of the delivery. There are delivery wheels mounted on a shaft over the delivery belt(s) which may be adjusted for different sheet sizes. These wheels stop the sheets and keep them on the delivery belt(s). To prevent signatures from inserting, (which may occur when delivering light weight or springy sheets), the delivery may be adjusted in its height. The speed of the delivery belt(s), driven by a D.C. motor, may be regulated by use of the potentiometer control button, which is located at the delivery operator control station. The operator may achieve the desired stream of the sheets by increasing or decreasing the speed of the belt(s).

Two cables, i.e. one (1) power supply and one (1) control cable, are connected to the delivery. If the delivery is used with the parallel section, these cables must be plugged into the designated sockets of the main control cabinet. If the 2nd, 3rd, or 4th folding unit is used, the delivery control cable and the power supply cable of the delivery must be plugged into the appropriate sockets of the preceding unit.

Summary

The quality and quantity of work which may be produced with the MBO folding machine depends on the care of the operator during his adjustment and alignment work. Jam-up's or inaccurate folding which do not relate to the condition of the pile or mechanical faults, mostly occur due to inaccurate adjustments or settings. In such a case, the operator should investigate whether all adjustments or settings are in accordance with the Operating Manual.

SAFETY FIRST


CAUTION:

If mechanical failure should occur, all repairs should be made by qualified service personnel, and therefore must be executed by them or under their supervision only. Any disregard of this safety regulation may cause damage to the machine. To avoid any kind of injuries do not, under any circumstances, attempt to work on or over the machine with tools of any kind while it is running.

Maintenance:


1. The entire machine is equipped with sealed ball bearings.
2. Lubricate the hand wheel per instructions below.
3. Clean and/or change pump filters as necessary.

Safety Handwheel




Lubricate with oil (1)


every 200 hours




The solenoid requires periodic cleaning. Spray power can cause the piston to get stuck. If the machine refuses to feed or constantly feeds with no sheet separation when the blue feeder button is pressed, please check and clean the solenoid before calling for a technician.



B18/T46-49/B23




EDGE TRIM RUBBER TIRES
 T49/B23 # 2.0.5539.040
 B123/T65-75/B26-30 # 50-220-130S



B123/ T65-75/B26-30

B26/B30

BELT LIST		PART NO.	IDENT. NO.	
1.	FOLD ROLLER DRIVE BELT PARALLEL 4 PLATE	25x1x1540	0106260	
	8-PAGE 4 PLATE	25x1x1540	0106260	
	16-PAGE 4 PLATE	25x1x1540	0106260	
	32-PAGE 2 PLATE	25x1x1290	0106211	
2.	SUCTION WHEEL DRIVE BELT	20x1x2300	0105908	
3.	REGISTER TABLE BELT	50x1.3x2100	0106924	
4.	MAIN DRIVE POLY V-BELT			
	PARALLEL WITH CONTINUOUS FEEDER	380J8	0107565	
	8-PAGE UNIT	400J8	0107839	
	16-PAGE UNIT	400J8	0107839	
	32-PAGE UNIT	340J8	0107540	
5.	CROSS CARRIER ROLLER DRIVE 8-PAGE	20x3480NE17	0106179	
	16-PAGE	20x3480NE17	0106179	
	32-PAGE	20x1x2540	0106021	
6.	DELIVERY TAPES MODEL A76 (8 USED)	40x1x1360	0106823	
7.	CONTINUOUS FEEDER TOP BELT	550X4405	0107061	
8.	CONTINUOUS FEEDER BOTTOM BELT	550x4660	0107064	
9.	CONTINUOUS FEEDER REAR TEXTILE BELTS (OLD STYLE ONLY) (4 USED)	50x2520	0106928	
10.	DOUBLE STREAM DEVICE			
	CONVEYOR DRIVE TIMING BELT	110xL037	0102343	
	CONVEYOR TAPES 8-PAGE (3 USED) B26	20x1.8x765	0105259	
		B30	0105338	
	CONVEYOR TAPES 16-PAGE (3 USED)	20x480	0105130	
11.	FOLD PLATE BELTS			
	PARALLEL			
		NO. 1	01.5673.11	01.5673.03
		NO. 2	01.5673.10	01.5673.02
		NO. 3	01.5673.07	01.5673.01
		NO. 4	01.5673.08	01.5673.01
	8-PAGE	NO. 1	01.5673.09	01.5673.02
		NO. 2	01.5673.10	01.5673.02
		NO. 3	01.5673.07	01.5673.01
		NO. 4	01.5673.08	01.5673.01
	16-PAGE	NO. 1	01.5673.07	01.5673.01
		NO. 2	01.5673.08	01.5673.01
		NO. 3	01.5673.07	01.5673.01
		NO. 4	01.5673.08	01.5673.01
	32-PAGE	NO. 1	01.5673.07	01.5673.01
		NO. 2	01.5673.06	01.5673.00



- A. When installing perforator, note angle of notch.
- B. Flat side of perforator and cutting knife must contact sharp side of lower knife.
- C. The threaded nut of the knife holder "D" tightens against the running direction of the shaft.


MBO TM32-A

SCORING, SLITTING AND PERFORATING KNIVES FOR SLITTER SHAFTS WITH 1 3/8" (35-mm) DIAMETER


Index #	Part #	O/D		Thickness		Split		Application
		Inch	mm	Inch	mm		Closed	
SCORES								
1	50210020	2 3/8	59.5	1/32	0.8	•		Standard score
2	50210220	2 3/8	60.0	1/32	0.8	•		Heavy score, such as in 16-page section for 32-page signature
3	50210550	2 5/16	58.8	1/32	1.0	•		Score against rubber, for cover stock or very heavy paper
4	50210860	2 7/16	61.5	1/16	1.5		•	Wide score, for maps or 32-page signatures
SLITTERS								
5	50210030	2 7/16	61.5	1/64	0.5	•		Standard slitter
6	50210260	2 7/16	61.5	1/64	0.5		•	For knife-to-knife slitting
7	50210480	2 9/16	64.0	1/64	0.5		•	For slitting very heavy work
8	50210760	2 7/16	61.5	1/64	0.5		•	High-speed steel slitter, for extra clean cut edges
9	50210250S	2 7/16	61.5	1/8	3.0		•	Heavy-duty slitter, for knife-to-knife slitting

All scores and slitters 1 9/16" (40mm) internal diameter. Inch measurements are approximate.

10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27



28




29




30




31




32



33



SPACER



1 = 1/4 Durchmesser 40 x 50 x 0.5 DIN 988
 3 = 3/4 Durchmesser 40 x 50 x 1 DIN 988

look in the direction of the arrow A
 60.830.070
 01.5539.01

14mm max 3 x 4.0.5544.090

2.0.5586.040

A

1.0.5564.300

50.370.040

4 min.
14 max

50.210.010

10.5564.300

2.0.5544.020

ULS M5 x 12

A 5.3 DIN 125

M5 x 16 DIN 653

2.0.5544.010



CODE 2635

PART NO. 01.5500.05

B 26/B 30/B 123

MBO

Center bleed trim device
 Gully cut device



MULTIPLE PERF AND CREASING DEVICE



MULTIPLE PERF AND CREASING DEVICE

MULTIPLE PERF AND CREASING DEVICE
FOR 35 mm SHAFTS

* FOR T65/75 USE 1.0.5500.040

STRIPPER ONLY IS 1.0.5586.040

CODE 2670 PART NO. 5.0.5500.030 (B123, B26, B30)
CODE 6570 AND 1.6.5500.110 (T65/T75)




CODE 2674

PART NO. 01.5500.07

B 26/B 30/B123

MBO Crimp-lock device

look in the direction of the arrow, A



5.0.5585.050

CODE 2652

PART NO. 01.5500.06

B 26/B 30' / B123

MBO

Edge trim device

4.0.5500.040

M6x12 DIN 913


60 500 140

M6x10 DIN 913

6x4 DIN 125

4.0.5585.050

50 370 040



Thickness	Teeth	Part - Nr
08mm	10Z	60 210 260
08mm	12Z	60 210 270
12mm	12Z	60 210 280

Thickness	Part - Nr
0,63 mm	01.5565.00
1,0 mm	01.5565.01

M5x16 DIN 913
1.05544.310

Look in the direction of the Arrow.

CODE 2662

PART NO. 01.5500.04

MBO
 B 26/B 30 / B123
 Stanzperforiereinrichtung
 Punch perforating device

PERFORATORS

Index #	Part #	O/D		Teeth		Cut Length		Bridge Length		Thickness	
		Inch	mm	Qty	Per Inch	Inch	mm	Inch	mm	Inch	mm
10	50210060	2 7/16	61.5	18	2.3	5/16	8	1/8	3	1/64	0.5
11	50210050	2 7/16	61.5	12	1.6	1/2	13	1/8	3	1/64	0.5
12	50210970	2 7/16	61.5	16	2.1	5/16	8.5	1/8	3.5	1/64	0.5
13	50210070	2 7/16	61.5	28	3.7	1/16	2	3/16	4.9	1/64	0.5
14	50210040	2 7/16	61.5	8	1	13/16	21	1/8	3	1/64	0.5
15	50210450	2 7/16	61.5	10	1.3	11/16	17	1/8	2.5	1/64	0.5
16	50210460	2 7/16	61.5	14	1.8	7/16	12	1/16	1.85	1/64	0.5
17	50210470	2 7/16	61.5	16	2.1	7/16	10.5	1/16	1.5	1/64	0.5
18	50210730	2 7/16	61.5	8	1	7/8	22	1/16	1.8	1/64	0.5
19	50210630	2 7/16	61.5	6	0.8	1 3/16	30	1/8	2.5	1/64	0.5
20	50210230	2 3/8	60.0	80	10.8	1/16	1.1	1/16	1.2	1/64	0.5
21	50210240	2 3/8	60.0	48	6.5	1/8	2.4	1/16	1.5	1/64	0.5
22	50210210	2 3/8	61.0	28	3.7	3/16	5	1/16	1.8	1/64	0.5
23	50210720	2 3/8	60.0	36	4.9	1/8	2.7	1/8	2.5	1/64	0.5
24	50210390	2 3/8	60.0	18	2.2	3/8	9	1/16	1.5	1/64	0.5
25	50210400	2 7/16	61.5	8	1	11/16	18	1/4	6	1/64	0.5
26	50210410	2 7/16	61.5	12	1.6	3/8	10	1/4	6	1/64	0.5
27	50210420	2 7/16	61.5	18	2.4	1/4	6	3/16	5	1/64	0.5
28	60210260	2 7/16	62.0	10	1.3	7/16	11.8	5/16	8	1/32	0.8
29	60210270	2 1/2	63.0	12	1.5	7/16	10.5	1/4	6	1/32	0.8
30	60210280	2 7/16	62.0	12	1.6	5/16	8.2	5/16	8	1/16	1.2
31	60210300	2 1/2	64.0	12	1.5	7/16	10.5	1/4	6	1/32	0.8
32	50211160	2 7/16	61.5	15	2	3/8	9	3/16	4	1/64	0.5
33	5.0.5591.060	2 7/16	61.5	18	2.3	3/16	4	1/4	7	1/64	0.5

All perforators 1 9/16" (40mm) internal diameter. Punch perforators are closed (not split-type); all others split-type. Inch measurements, cut length and bridge length dimensions are approximate.

PERFORATORS

#	Perf Type	Signature	Stock Weight	Application
10	Head	16-Page	Light	
11	Head	16-Page	Medium	
12	Head	16-Page	Heavy	
13	Head	16-Page	Med./heavy	Reduces dog ears; also for automatic sewing
	Spine	16-Page	Light/med.	Perfect binding, high tear strength
14	Head	32-Page	Med./heavy	
15	Head	32-Page	Light	Less creasing than perforator #14
16	Head	32-Page	Very light	Less creasing than perforator #15
17	Head	32-Page	Lightest	Less creasing than perforator #16
18	Head	32-Page	Lightest	Hard thin stock such as diary papers
19	Head	32-Page	Lightest	Hard thin stock such as diary papers
20	Tearout	4-Page	Light	Light tear strength
21	Tearout	6-Page	Light/med.	Mailer: medium tear strength
22	Tearout	8-Page	Heavy	High tear strength
23	Tearout	12-Page	Heavy	Mailer: multiple-perf: highest tear strength
24	Tearout	8-Page	Light	Snap-out sets
25	Spine	32-Page	All	Perfect binding
26	Spine	16-Page	All	Perfect binding
27	Spine	16-Page	All	Perfect binding
	Head	16-Page	All	Automatic sewing
28	Spine	16-Page	Light/med.	Punch perf for sigs up to 1/32" thick
29	Spine	32-Page	Light/med.	Punch perf for sigs over 1/32" thick
30	Spine	16-Page	Light/med.	Punch perf for hot-melt gluing
31	Spine	32-Page	Heavy	Punch perf for sigs over 1/32" thick
32	Head	16-Page	Med./heavy	Automatic sewing
33	Spine	16-Page	Heavy	Saddle stitching